



NOTES:

- 1) ALL MATERIALS ARE INCLUDED WITH THE STREET LIGHTING POLE CONSTRUCTION BILL OF MATERIAL.
- 2) CONNECTION MUST BE ACCORDING TO MANUFACTURER'S INSTRUCTIONS.
- 3) THIS LINE SUPPLY MUST BE CONNECTED TO THE LINE-SIDE RECEPTACLE AND THE LOAD TO THE LOAD-SIDE RECEPTACLE. ⚠
- 4) WHEN A FUSEHOLDER IS INSTALLED IN AN OVERHEAD SITUATION, ENSURE THAT THERE IS MINIMAL TENSION ON THE CRIMP CONNECTIONS OF THE FUSEHOLDER. ⚠
- 5) ALL SIZES OF LUMINAIRE ARE FUSED WITH A 10A FUSE. ⚠
- 6) THE 10A FUSE IS NOT SUPPLIED WITH THE FUSEHOLDER. ⚠
- 7) BEFORE PLACING INTO SERVICE, TEST FUSEHOLDER ASSEMBLY BY SEPARATING PLUG & RECEPTACLE COMPONENTS AND CHECK THAT FUSE IS RETAINED IN THE LOAD-SIDE RECEPTACLE. ⚠
- 8) THIS IS A TYPICAL INSTALLATION. FOR SOME MAKES OF FUSEHOLDERS. THE CAPTIVE NUT MAY BE ON LINE-SIDE RECEPTACLE.
- 9) USE NICOPRESS TMJ CRIMP TOOL - J GROOVE.

DISTRIBUTION CONSTRUCTION STANDARD
Street Lighting



Approved By:
I.S. 2011-10-27
Drafted By:
S.P.
Designed By:
A.F.A.

Original Issue:
L.G. 2001-01-15

Scale:
N.T.S.

Rev: 2

30-3200

1/1

INSTALLATION DETAIL
LUMINAIRE FUSE ASSEMBLY